

Glass Burst Pouch Application

- 1) Put the rubber stopper in the dispensing tube**
 - 2) Squeeze the lower pocket until it pops into the larger pocket**
 - 3) Mix by squeezing one pocket then the other for 2 minutes**
 - 4) Squeeze the big pocket until it pops into the dispensing pocket**
 - 5) Dispense onto sponge or paper towel and re cork the tube**
 - 6) Wipe onto window, then buff off with paper towel. Do not let dry more then 10 seconds**
 - 7) Repeat for other glass surfaces**
 - 8) Once mixed the product should be used within 18 hours, after which it will spoil**
-